


# Zirconium oxide – Preparation


## Single crowns and up to 6-unit bridges

Evenly reduce the anatomical shape and observe the stipulated minimum thicknesses. Prepare a circular shoulder with rounded inner edges or chamfer. The width of the circular shoulder/ chamfer is approx. 1 mm. Reduce the crown third – incisal or occlusal areas – by approx. 1.2 mm. Reduce the incisal and occlusal areas by approx. 1.5 mm.

The incisal edge of the preparation should be at least 1 mm (milling tool geometry) in order to permit optimum milling of the incisal edge during CAD/CAM processing.



## Multi-unit bridges



Further information can be found in the corresponding literature.